



PLEASE NOTE THAT WE HAVE INSTALL VIDEOS FOR MANY MODELS ON GOOGLE VIDEO AND YOUTUBE.COM. SEARCH UNDER "WIND DEFLECTOR"

Wind Deflector Miata 1989 to 2004 Installation Guide

START BY PUTTING YOUR TOP DOWN

STEP 1: TO INSTALL YOUR WIND DEFLECTOR YOU WILL NEED TO REMOVE A PUSH PIN AND ADD IN SCREW IN ITS PLACE. THE PUSH PIN IS LOCATED BELOW THE SEAT BELT MECHANISM



STEP 1 CONT: TO REMOVE THE PUSH PIN USE A THIN SCREW DRIVER AND GENTLE LIFT THE MIDDLE SECTION OF THE PUSH PIN



STEP 1 CONT: ONCE THE MIDDLE HAS BEEN PUSHED OUT YOU CAN REMOVE THE PUSH PIN. DO THIS ON BOTH SIDES



STEP 2: NEXT YOU NEED TO ATTACH THE TUBE BRACKETS TO YOUR MIATA. IN THIS PHOTO YOU SEE THE TUBE BRACKET, THE SILVER SCREW THAT REPLACES THE PUSH PIN AND AN EXISTING SCREW.



STEP 2 CONT: THE TUBE BRACKET IS ATTACHED USING THE SILVER SCREW WHICH GOES INTO THE TOP HOLE (THIS IS THE HOLE THAT THE PUSH PIN WAS REMOVED). THE BOTTOM SCREW IS A SCREW THAT WAS ALREADY IN. YOU WILL ONLY HAVE TO DO THIS ONCE FOR YOUR MIATA.



STEP 2 CONT: THE SHAFT BRACKET WHICH IS ATTACHED TO THE WIND DEFLECTOR SLIDES INTO THE SIDE TUBE BRACKET. REPEAT TO THE OTHER SIDE.



PLEASE NOTE; THAT THE SHAFT BRACKET FACES TOWARDS THE BACK OF YOUR MIATA.



STEP 3: THE WIND DEFLECTOR IS SUPPORTED BY THE SHAFT BRACKET AND SITS BEHIND THE TUBE BRACKETS



STEP 4: THE LAST STEP IS TO ATTACH THE TWO ELASTIC STRAPS WITH THE SNAPS ON IT ON TO THE FLOOR OF THE BACK SEAT.



STEP 4 CONT. IF YOUR CAR DOES NOT COME WITH THE SNAPS, ATTACH THE STRAPS WITH THE VELCRO BACKING AND ATTACH THEM TO YOUR RUG.



NOW YOU ARE READY TO LOVE THE DRIVE
WWW.LOVETHEDRIVE.COM